

Name: Cheung Tsz Chun Noddy


ID: 220171174

Subject: MBS4544

a)


```
hc sr04 test > src > main.cpp > loop()
1  #include <Arduino.h>
2  #include <HCSR04.h>
3
4  UltrasonicDistanceSensor distanceSensor(13, 12); // Initialize sensor that uses digital pins 13 and 12.
5
6  void setup () {
7      Serial.begin(9600); // We initialize serial connection so that we could print values from sensor.
8  }
9
10 void loop () {
11     // Every 1 second, do a measurement using the sensor and print the distance in centimeters.
12     double distance = distanceSensor.measureDistanceCm();
13     Serial.print(F("°C - Distance: "));
14     Serial.print(distance);
15     Serial.println(F("cm"));
16     delay(1000);
17 }
```

```
°C - Distance: 17.54cm
°C - Distance: 21.66cm
°C - Distance: 59.84cm
°C - Distance: 15.93cm
°C - Distance: 16.24cm
°C - Distance: 21.95cm
°C - Distance: 17.54cm
°C - Distance: 200.40cm
°C - Distance: 201.80cm
°C - Distance: 200.91cm
°C - Distance: 29.12cm
```



b)

```
Distance: 34.52cm
Distance: 34.27cm
Distance: 34.01cm
Distance: 34.01cm
Distance: 31.40cm
Distance: 14.92cm
Distance: 14.61cm
Distance: 15.25cm
Distance: 15.56cm
Distance: 15.25cm
Distance: 14.27cm
Distance: 13.94cm
Distance: 13.94cm
Distance: 15.23cm
Distance: 14.92cm
Distance: 14.92cm
Distance: 14.61cm
Distance: 14.59cm
Distance: 14.59cm
Distance: 15.25cm
Distance: 14.59cm
Distance: 14.59cm
Distance: 14.92cm
Distance: 15.25cm
Distance: 15.25cm
Distance: 15.25cm
```



```
T53 > src > main.cpp > loop()
1  #include <Arduino.h>
2  int readPin = 25;
3  float scale = 0.0f;
4  float minimum = 15.0f;
5  float maximum = 60.0f;
6  float adc_max = 4096.0f;
7  double distance = 0;
8
9  void setup () {
10 |   Serial.begin(9600); // We initialize serial connection so that we could print values from sensor.
11 | }
12
13 void loop () {
14 |   // Every 1 second, do a measurement using the sensor and print the distance in centimeters.
15 |   float x = analogRead(readPin);
16 |   scale = (float)((maximum - minimum) / adc_max);
17 |   distance = (float) scale * x + minimum;
18 |
19 |   Serial.print(F("Distance: "));
20 |   Serial.print(distance);
21 |   Serial.println(F("cm"));
22 |   // Serial.println(x);
23 |   delay(1000);
24 | }
25
```

c)

```

hc sr04 test > src > main.cpp > loop()
1  #include <Arduino.h>
2  #include <HCSR04.h>
3
4  int readPin = 25;
5  float scale = 0.0f;
6  float minimum = 15.0f;
7  float maximum = 60.0f;
8  float adc_max = 4095.0f;
9  float distance = 0.0f;
10 float offset = 0.0f;
11
12 UltraSonicDistanceSensor distanceSensor(13, 12); // Initialize sensor that uses digital pins 13 and 12.
13
14 void setup() {
15     Serial.begin(9600); // We initialize serial connection so that we could print values from sensor.
16 }
17
18 void loop() {
19     // Measure distance using the analog sensor
20     float x = analogRead(readPin);
21     scale = (float)((maximum - minimum) / adc_max);
22     distance = (float) (scale * x + minimum - offset);
23
24     Serial.print(F("Analog Distance: "));
25     if (distance <= minimum){
26         Serial.print("<=");
27     }
28     else if(distance >= maximum){
29         Serial.print(">=");
30     }
31     Serial.print(distance);
32
33     Serial.println(F("cm"));
34
35     // Measure distance using the ultrasonic sensor
36     double ultrasonicDistance = distanceSensor.measureDistanceCm();
37
38     Serial.print(F("Ultrasonic Distance: "));
39     Serial.print(ultrasonicDistance);
40     Serial.println(F("cm"));
41
42     delay(1000);
43 }

```

d) Fill the table. (Total: 10%)


	Ultrasonic (HC-SR04)	Laser (DT35)
Valid measuring range (mm)	20 ~ 4000	50-12,000
Accuracy (mm)	±3	±10
Frequency (Hz)	40	Switching frequency: 166 Hz/50 Hz/25 Hz/12 Hz/3 Hz
Around price (HKD)	35.00	5,221.12

5) i),ii),iii)

Items: transparent bottle with water


15cm

i	5	10	15	20	25	30
	Analog Distance: 21.08cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.19cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 16.84cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.15cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.16cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.15cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.19cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.15cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.15cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.14cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.10cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.22cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.15cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					
	Analog Distance: 21.15cm $\frac{V_A}{V_B}$					
	Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$					




25cm

Analog Distance: 33.65cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.57cm $\frac{V_A}{V_B}$	
Analog Distance: 33.66cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 15.56cm $\frac{V_A}{V_B}$	
Analog Distance: 31.18cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.14cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.16cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.14cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.15cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.13cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.26cm $\frac{V_A}{V_B}$	
Analog Distance: 31.11cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.08cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.19cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.18cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	
Analog Distance: 31.19cm $\frac{V_A}{V_B}$	
Ultrasonic Distance: 26.24cm $\frac{V_A}{V_B}$	




50cm

1	5	10	15	20	25	30
Analog Distance: 59.80cm						
Ultrasonic Distance: 51.04cm						
Analog Distance: 59.31cm						
Ultrasonic Distance: 51.02cm						
Analog Distance: 58.43cm						
Ultrasonic Distance: 51.02cm						
Analog Distance: 57.41cm						
Ultrasonic Distance: 50.68cm						
Analog Distance: 58.76cm						
Ultrasonic Distance: 50.68cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 51.02cm						
Analog Distance: 57.73cm						
Ultrasonic Distance: 50.18cm						
Analog Distance: 59.15cm						
Ultrasonic Distance: 50.68cm						
Analog Distance: 58.60cm						
Ultrasonic Distance: 50.68cm						
Analog Distance: 59.33cm						
Ultrasonic Distance: 50.68cm						
Analog Distance: 58.43cm						
Ultrasonic Distance: 50.68cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 50.68cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 50.16cm						



60cm

1	5	10	15	20	25	30
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.36cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 60.21cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.77cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.78cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.77cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.36cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.78cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.36cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.78cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.36cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.78cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.78cm						
Analog Distance: >=60.00cm						
Ultrasonic Distance: 59.36cm						




Tissue(sponge):

15cm

```

Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 14.92cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 14.59cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 14.92cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 15.88cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 14.90cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 15.88cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 14.59cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 15.88cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 14.92cm ✓ ✓
Analog Distance: <=15.00cm ✓ ✓
Ultrasonic Distance: 14.90cm ✓ ✓

```




25cm

```


Analog Distance: 24.20cm ✓ ✓
Ultrasonic Distance: 26.24cm ✓ ✓
Analog Distance: 24.15cm ✓ ✓
Ultrasonic Distance: 25.36cm ✓ ✓
Analog Distance: 23.99cm ✓ ✓
Ultrasonic Distance: 28.78cm ✓ ✓
Analog Distance: 24.04cm ✓ ✓
Ultrasonic Distance: 25.36cm ✓ ✓
Analog Distance: 23.98cm ✓ ✓
Ultrasonic Distance: 25.36cm ✓ ✓
Analog Distance: 23.87cm ✓ ✓
Ultrasonic Distance: 25.36cm ✓ ✓
Analog Distance: 23.95cm ✓ ✓
Ultrasonic Distance: 25.38cm ✓ ✓
Analog Distance: 23.98cm ✓ ✓
Ultrasonic Distance: 25.36cm ✓ ✓
Analog Distance: 23.91cm ✓ ✓
Ultrasonic Distance: 28.78cm ✓ ✓
Analog Distance: 23.93cm ✓ ✓
Ultrasonic Distance: 26.24cm ✓ ✓
Analog Distance: 23.95cm ✓ ✓
Ultrasonic Distance: 28.78cm ✓ ✓
Analog Distance: 23.95cm ✓ ✓
Ultrasonic Distance: 28.76cm ✓ ✓
Analog Distance: 23.97cm ✓ ✓
Ultrasonic Distance: 26.58cm ✓ ✓

```




50cm

```
Analog Distance: 59.80cm
Ultrasonic Distance: 51.04cm
Analog Distance: 59.31cm
Ultrasonic Distance: 51.02cm
Analog Distance: 58.43cm
Ultrasonic Distance: 51.02cm
Analog Distance: 57.41cm
Ultrasonic Distance: 50.68cm
Analog Distance: 58.76cm
Ultrasonic Distance: 50.68cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 51.02cm
Analog Distance: 57.73cm
Ultrasonic Distance: 50.18cm
Analog Distance: 59.15cm
Ultrasonic Distance: 50.68cm
Analog Distance: 58.60cm
Ultrasonic Distance: 50.68cm
Analog Distance: 59.33cm
Ultrasonic Distance: 50.68cm
Analog Distance: 58.43cm
Ultrasonic Distance: 50.68cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 50.68cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 50.16cm
```




60cm

```
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.36cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 60.21cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.77cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.78cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.77cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.36cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.78cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.36cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.78cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.36cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.78cm
Analog Distance: >=60.00cm
Ultrasonic Distance: 59.36cm
```




transparent ruler:

15cm



	1	5	10	15	20	25	30
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	15.56cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	15.56cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	16.19cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	15.56cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	14.90cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	16.19cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	15.23cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	14.92cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	15.88cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	15.88cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	14.58cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	14.59cm						
Analog Distance:	<=15.00cm						
Ultrasonic Distance:	14.92cm						


25cm



	1	5	10	15	20	25	30
Analog Distance:	23.74cm						
Ultrasonic Distance:	23.62cm						
Analog Distance:	23.54cm						
Ultrasonic Distance:	21.57cm						
Analog Distance:	23.46cm						
Ultrasonic Distance:	26.58cm						
Analog Distance:	23.23cm						
Ultrasonic Distance:	28.25cm						
Analog Distance:	23.37cm						
Ultrasonic Distance:	26.58cm						
Analog Distance:	23.36cm						
Ultrasonic Distance:	26.60cm						
Analog Distance:	23.42cm						
Ultrasonic Distance:	27.41cm						
Analog Distance:	23.56cm						
Ultrasonic Distance:	25.66cm						
Analog Distance:	23.58cm						
Ultrasonic Distance:	25.36cm						
Analog Distance:	23.52cm						
Ultrasonic Distance:	27.99cm						
Analog Distance:	23.55cm						
Ultrasonic Distance:	26.24cm						
Analog Distance:	23.49cm						
Ultrasonic Distance:	25.36cm						
Analog Distance:	23.60cm						
Ultrasonic Distance:	27.41cm						


50cm

```
Analog Distance: 40.49cm V V
Ultrasonic Distance: 46.68cm V V
Analog Distance: 43.53cm V V
Ultrasonic Distance: 44.47cm V V
Analog Distance: 43.97cm V V
Ultrasonic Distance: 49.99cm V V
Analog Distance: 44.71cm V V
Ultrasonic Distance: 49.99cm V V
Analog Distance: 44.34cm V V
Ultrasonic Distance: 50.32cm V V
Analog Distance: 44.68cm V V
Ultrasonic Distance: 50.32cm V V
Analog Distance: 44.43cm V V
Ultrasonic Distance: 49.99cm V V
Analog Distance: 43.87cm V V
Ultrasonic Distance: 49.48cm V V
Analog Distance: 44.69cm V V
Ultrasonic Distance: 49.48cm V V
Analog Distance: 45.19cm V V
Ultrasonic Distance: 49.82cm V V
Analog Distance: 44.76cm V V
Ultrasonic Distance: 49.82cm V V
Analog Distance: 45.27cm V V
Ultrasonic Distance: 49.48cm V V
Analog Distance: 44.90cm V V
Ultrasonic Distance: 49.48cm V V
```



60cm

```
1 5 10 15 20 25 30
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 59.36cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 59.36cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 59.77cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 59.63cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 59.20cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 58.24cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 58.22cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 58.21cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 58.22cm V V
Analog Distance: >=60.00cm V V
Ultrasonic Distance: 58.22cm V V
Analog Distance: 47.98cm V V
Ultrasonic Distance: 58.22cm V V
Analog Distance: 48.64cm V V
Ultrasonic Distance: 58.22cm V V
Analog Distance: 49.19cm V V
Ultrasonic Distance: 57.80cm V V
```



- iv. "U" stands for ultrasonic sensor, "L" stands for laser sensor. Fill the table. (15%)

	Transparent bottle with water	Tissue(sponge)	Transparent ruler
Error (mm)	U: ± 0.65 , L: ± 6.90	U: ± 1.30 , L: ± 1.03	U: -0.695 , L: -3.45
Stability and Performance (description)	<p>Ultrasonic sensor ("U"): Error ± 0.65cm Better stability (smaller error margin) Higher accuracy</p> <p>Laser sensor ("L"): Error ± 6.90cm Lower stability (larger error margin) Lower accuracy</p> <p>Laser performance can be affected by transparency and refraction issues</p>	<p>Ultrasonic sensor ("U"): Error ± 0.65cm Lower stability (larger error margin) Lower accuracy</p> <p>Laser sensor ("L"): Error ± 6.90cm Better stability (smaller error margin) Higher accuracy</p> <p>Ultrasonic sensor performance can be affected by the sponge material, and it may absorb some sounds</p>	<p>Ultrasonic sensor ("U"): Error -0.695cm Better stability (smaller error margin) Higher accuracy</p> <p>Laser sensor ("L"): Error -3.45cm Lower stability (larger error margin) Lower accuracy</p> <p>Laser performance can be affected by transparency of the ruler</p>

F) Give a suitable situation / application of each sensor and why. (Total: 10%)

Ultrasonic HC-SR04 Sensor:

- Used in robotics for obstacle detection and avoidance.
- Example: In a robot vacuum cleaner, it helps the device navigate around a room without bumping into furniture or walls.
- It sends out ultrasonic waves that bounce back when they hit an object. The time taken for the waves to return helps calculate the distance to the object.
- Inexpensive, reliable performance

Laser DT35 Sensor:

- Used for safe presence monitoring in intralogistics.
- Example: In an automated warehouse system, it ensures that the path of an automated guided vehicle (AGV) is clear before it starts moving.
- It uses laser technology to measure the distance to any potential obstacles. If an obstacle is detected within a certain range, the AGV can be programmed to stop or change its path.
- Long range

Choosing between the two sensors:

- Depends on factors such as required range, accuracy, cost, and environmental conditions.
- HC-SR04 is generally cheaper and easier to use, suitable for hobbyist projects and simple applications.
- DT35 offers higher accuracy and longer range, suitable for more demanding industrial applications.